

Your Lock-n-Haul has been preadjusted to fit your Evinrude G2-150hp motor. To install it follow the instructions below.

1. Straighten motor.
2. Raise motor high enough to insert both ends of the Lock-n-Haul.
3. Insert flat ends into bottom sets of recessed lower motor mounts.
4. Hold flat ends of Lock-n-Haul against lower motor mount flange bolts.
5. Slowly lower rounded ends into indents in transom mounting bracket.
6. Check that all four ends are solidly in contact with motor and bracket.
7. Lower motor until tilt motor changes sound indicating that it has bottomed out.
8. Pass safety retainer cable around tilt piston and attach with carabiner.

