

## **Lock-n-Haul® Advanced Motor Toter** **Install on Evinrude G2 Outboard**

**1.**

**Raise motor enough to allow the flat ends to be inserted into the bottom set of flange bolt recesses, and the roundends will clear the 'tray'.**



**2.**

**Maintain contact with the flange bolts and the bottom side of the trim pistons, by pushing the device back toward prop, and upward toward the top of the motor at the same time.**

**3.**

**Hold the device in place and lower the motor until the tilt motor changes sound. You are now ready to trailer your motor with confidence**



**4.**

**Pass safety lanyard around the trim ram and attach the carabiner back onto the lanyard. Notice on photo do not locate round ends of Lock-n-Haul on the 'fence' at the front of the tray. The round ends go to the rear wall.**



**Scan this QR code to see the video on the installation of this device.**

